ESCREO

Initial Preparations

- 1. Each box includes: installation instructions, whiteboard paint, paint hardener, can opener and stirrer.
- 2. You will also need: paint roller, tape, protective cover, sanding box and gloves.
- 3. Use tape to frame your ESCREO area.
- 4. Smooth the surface with the sanding block.
- 5. Use the gloves and, if possible, eye protection.



Watch our video tutorials in ESCREO YouTube Channel.



Find the section that applies to you:

Whiteboard Paint - White/Clear

/Apply the paint no later than 2 hours after mixing the 2 components/

- 1. Open the tins with the tin opener carefully.
- 2. Use the stirrer to mix the 2 components for 5 min.
- 3. Pour half of the mixture into a tray.
- 4. Close the rest of the paint in the tin.
- 5. Apply the 1st layer evenly with a paint roller/brush.
- 6. Wait between 30 min. and 45 min.
- 7. Apply the 2nd layer and proceed to "Wrap-up!" section.
- 8. After mixing the two components DO NOT leave the mixture with a closed lid for more than 2 HOURS. If not applied up to 2 hours and let closed, it might pop up.

Magnetic Whiteboard Paint - Base

/1 extra day for the application process/

- 1. Stir well the magnetic paint.
- 2. Use an extra paint tray & roller to apply the 1st layer.
- 3. Wait 30 min.
- 4. Apply the 2nd layer.
- 5. Wait 45 min.
- 6. Apply the 3rd layer.
- 7. Wait 60 min.
- 8. Apply the 4th layer.
- 9. Remove the tape.
- 10. Wait for 12 hrs.
- 11. Smooth the surface with the sanding block in straight motions.
- 12. Proceed to "Primer" section.

Primer

/To change the colour of the surface or after applying the magnetic paint base/

- 1. Use an extra tray and a paint roller sleeve to apply the 1st layer.
- 2. Wait between 30 and 60 min.
- 3. Apply the 2nd layer.
- 4. Wait between 30 and 60 min.
- 5. Proceed to "Whiteboard Paint White/Clear"

section.

Wrap up!

/NB! Only start writing 3 days after the paint has dried/

- 1. Make sure the paint is distributed evenly.
- 2. Remove the painting tape.
- 3. Place the "Wet Paint" sign.
- 4. Let it dry for 3 days before using the wall.
- 5. Check our website for maintenance guidelines.